

Name

		Pass 1		Pass 2	
BUFFER	Mode :	<input type="text" value="Double"/>		<input type="text" value="Double"/>	
		Forward	Reverse	Forward	Reverse
Distance - Ft.		<input type="text" value="39.0"/>	<input type="text" value="39.0"/>	<input type="text" value="25.0"/>	<input type="text" value="25.0"/>
OIL	Mode :	<input type="text" value="Double"/>		<input type="text" value="Double"/>	
Distances - Ft.		Forward	Reverse	Forward	Reverse
left outside :		<input type="text" value="20.0"/>	<input type="text" value="23.0"/>	<input type="text" value="10.0"/>	<input type="text" value="5.0"/>
left track :		<input type="text" value="28.0"/>	<input type="text" value="33.0"/>	<input type="text" value="12.0"/>	<input type="text" value="15.0"/>
left inside :		<input type="text" value="37.0"/>	<input type="text" value="35.0"/>	<input type="text" value="18.0"/>	<input type="text" value="20.0"/>
right inside :		<input type="text" value="37.0"/>	<input type="text" value="35.0"/>	<input type="text" value="18.0"/>	<input type="text" value="20.0"/>
right track :		<input type="text" value="28.0"/>	<input type="text" value="33.0"/>	<input type="text" value="12.0"/>	<input type="text" value="15.0"/>
right outside :		<input type="text" value="20.0"/>	<input type="text" value="23.0"/>	<input type="text" value="10.0"/>	<input type="text" value="5.0"/>
Transfer Rate %		<input type="text" value="20"/>	<input type="text" value="40"/>	<input type="text" value="20"/>	<input type="text" value="25"/>

Short Run	
Mode	<input type="text" value="Off"/>
Turn-around Distance	<input type="text" value="0.0"/> Ft.

Stripping	
Mode	<input type="text" value="Full"/>
Start	<input type="text" value="0.0"/> Ft.
Cleaner Pad Distance	<input type="text" value="61.5"/> Ft.
Vacuum	<input type="text" value="On Start"/>

Cleaner Flow	
In oil	<input type="text" value="100"/> %
Back lane	<input type="text" value="30"/> %

		Pass 1		Pass 2	
SPEED SETTINGS:		Forward	Reverse	Forward	Reverse
Travel		Medium	Medium	Medium	Medium
Condition		Medium	Medium	Medium	Medium
Strip		Medium			

Tournament Of Champions:

Divide the center tank wicks into two 5" sections:
 inside portions of each tank use Hi-flow wick material
 outside portion of each tank use Medium flow wick material
 Track and outside tanks use medium flow wick material.