



Select Machine

**Pattern Information**

Date: 17-Jan-17  
 Pattern Type:   
 Pattern Difficulty:   
 Pattern Designer: SEAN PARRY  
 Pattern Volume (ml): 30.26

**Pattern Parameters**

Pattern Number:   
 Pattern Name: 2017 TOC  
 Mode:   
 Forward Speed:   
 Start Cleaner Spray: 0  
 Start Squeegee: 0  
 Start Oiling: 6  
 Split Pattern: No

**Supplies Information**

Lane Cleaner: MAX 10  
 Cleaner Mixture Ratio: 10 : 1  
 Cleaner Transition Distance: 41  
 Cleaner Spray End Distance: 53  
 Lane Conditioner: DEFY 30


Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**Surface Information**

Surface Type: Synthetic  
 Surface Brand: Brunswick Pro Lane  
 Age: \_\_\_\_\_

Zone	1	2	3	4	5	6	7	8
Zone End Distance	12	22	27	32	39			
Zone Ratio	L 1.6 : 1	2.0 : 1	2.3 : 1	1.8 : 1	1.0 : 1	### : 1	### : 1	### : 1
	R 1.7 : 1	2.0 : 1	2.6 : 1	2.1 : 1	1.0 : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	15.97	9.47	3.23	1.59	0.00	0.00	0.00	0.00

ZONE	7 Pin Side										Board Number										10 Pin Side																		
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1
1	40	40	40	60	60	65	70	80	90	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	90	80	70	65	60	60	35	35	35
2	30	30	30	30	40	40	40	45	50	60	70	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	65	50	40	35	30	25	25	25	25
3	20	20	20	20	25	25	28	28	33	33	39	44	55	55	55	55	55	55	55	55	55	55	55	55	55	55	55	55	50	45	40	30	25	20	15	15	15	15	15
4	13	13	13	13	13	13	16	16	16	20	20	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	23	20	20	16	13	10	10	10	10	10	10
5	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
6																																							
7																																							
8																																							





**ENVOY AUTHORITY 22**

## 2017 TOC


### Crosswise Ratios (by units)

Zone 1 Average Ratio				Zone 5 Average Ratio			
3L-7L	Left =	59.0	1.6	3L-7L	Left =	1.0	1.0
3R-7R	Right=	58.0	1.7	3R-7R	Right=	1.0	1.0
18L-18R	Center =	100.0		18L-18R	Center=	1.0	
Zone 2 Average Ratio				Zone 6 Average Ratio			
3L-7L	Left =	36.0	2.0	3L-7L	Left =	#DIV/0!	#DIV/0!
3R-7R	Right=	36.0	2.0	3R-7R	Right=	#DIV/0!	#DIV/0!
18L-18R	Center=	75.0		18L-18R	Center=	#DIV/0!	
Zone 3 Average Ratio				Zone 7 Average Ratio			
3L-7L	Left =	23.6	2.3	3L-7L	Left =	#DIV/0!	#DIV/0!
3R-7R	Right=	21.0	2.6	3R-7R	Right=	#DIV/0!	#DIV/0!
18L-18R	Center=	55.0		18L-18R	Center =	#DIV/0!	
Zone 4 Average Ratio				Zone 8 Average Ratio			
3L-7L	Left =	13.6	1.8	3L-7L	Left =	#DIV/0!	#DIV/0!
3R-7R	Right=	11.8	2.1	3R-7R	Right=	#DIV/0!	#DIV/0!
18L-18R	Center =	25.0		18L-18R	Center=	#DIV/0!	

### Crosswise Ratios (by ml)

Zone 1 Average Ratio				Zone 5 Average Ratio			
3L-7L	Left =	0.297	1.6	3L-7L	Left =	0.000	#DIV/0!
3R-7R	Right=	0.292	1.7	3R-7R	Right=	0.000	#DIV/0!
18L-18R	Center =	0.503		18L-18R	Center=	0.000	
Zone 2 Average Ratio				Zone 6 Average Ratio			
3L-7L	Left =	0.151	2.0	3L-7L	Left =	0.000	#DIV/0!
3R-7R	Right=	0.151	2.0	3R-7R	Right=	0.000	#DIV/0!
18L-18R	Center=	0.314		18L-18R	Center=	0.000	
Zone 3 Average Ratio				Zone 7 Average Ratio			
3L-7L	Left =	0.049	2.3	3L-7L	Left =	0.000	#DIV/0!
3R-7R	Right=	0.044	2.6	3R-7R	Right=	0.000	#DIV/0!
18L-18R	Center=	0.115		18L-18R	Center =	0.000	
Zone 4 Average Ratio				Zone 8 Average Ratio			
3L-7L	Left =	0.029	1.8	3L-7L	Left =	0.000	#DIV/0!
3R-7R	Right=	0.025	2.1	3R-7R	Right=	0.000	#DIV/0!
18L-18R	Center =	0.052		18L-18R	Center=	0.000	

The crosswise ratios are calculated by the average units of oil for boards 18L - 18R and divided by the average units of oil for board 3 - 7 left and right.



<b>3L-7L:18L-18R</b>	<b>Ratio by Total Volume</b>	<b>18L-18R:7R-3R</b>
<b>1.87</b>	<b>1</b>	<b>1.93</b>

